

Smart WiFi

Indoor IP Camera

24/7 SECURITY FOR YOUR PROPERTY




1.0MP

IPC1020


1 Product Introduction

Packing List:

- Smart Camera x 1
- Manual x 1
- USB Power Cord x 1
- Power Adapter x 1
- Screw Accessories Package x 1




Smart Camera




Screw Accessories Package



USB Power Cord



Manual



Power Adapter

2 Basic Parameters

- **Product SKU:** IPC1020
- **Lens:** 110° Wide Angle
- **Pixel:** 1.0MP
- **Video Compression:** H.264 High Profile
- **Image Enhancement:** Digital Wide Dynamic 3D Noise Reduction
- **Local Storage:** MicroSD card
- **Wireless Encryption:** WEP/WPA/WPA2 Encryption
- **Power Input:** 5V 1A
- **Total Power Consumption:** 3.5W
- **Wireless Standard:** 2.4G 802.11 b/g/n
- **Support Platform:** Android/iOS

3 Component Description


Reset Button: Long Press “reset” hole 5 sec, there’s voice prompt “reset” camera successfully”, reset success.

It is recommended to insert 8-64GB high speed Micro SD card, otherwise it will not be able to store, view historical video and support important functions such as firmware upgrading.

4 Install App

Download App: Scan the QR code below to download and install.

Register and Login: Open the “ENERJSMART” app to register and login according to the prompts.



Also works with Amazon Alexa & Google Home, Google Assistant.






4 Add The Device

Please make sure that there is a available Wi-Fi and the internet is connected.


Find the USB interface at the bottom of the device and insert the power cord to connect with power.

Then go to App home page, click the “ADD DEVICES” on the main screen, and click the “Smart Camera”.

Select the “QR CODE” in the upper right corner, click confirm and add according to the mobile phone prompt.



4 App Video Browsing Details



1. Preview Mode
2. Monitor Switch
3. More Device
4. SQ
5. Full Screen
6. Play/Pause
7. History file (Make sure insert Micro SD card)

4 App Video Browsing Details

- Try to keep away from the metal space.
- Avoid the furniture, microwave oven blocked..
- Avoid the space where the audio, video and data lines wound, and keep the space away from them as large as possible.
- Ensure that as close as possible to the coverage of wireless Wi-Fi signals. Switching network environment.
- In the new network environment, please press the reset hole about 5 seconds, After hearing the voice prompt “reset camera successfully” and then connect to the network.

The name and content of the harmful substances in the product

Part Name	Harmful Substance					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
shell	○	○	○	○	○	○
Board	X	○	○	○	○	○
charger	○	○	○	○	○	○
annex	○	○	○	○	○	○
This form is based on the provisions of SJ/T 11364.						

This product conforms to RoHS environmental protection requirement. At present, there is no mature technology in the world to replace or reduce the lead content in the ceramics, porcelain, optical glass, steel and copper alloy.